



3500 CORPORATE PARKWAY
CENTER VALLEY, PA 18034-0610
DIGITAL TECHNICAL SUPPORT
CONSUMER PRODUCTS GROUP
(888) 553-4448
<http://support.olympusamerica.com>

DSS Player V6 Upgrade to V7 (v7.0.1)

Description:

This upgrade (DSSV7UPEN.EXE) applies to all DSS Player V6 version 6.3.2 and earlier. To check the current version of your DSS Player V6 software, start your DSS Player V6 application then click on the Help menu → About...

| <u>Release</u> | <u>Program Version</u> |
|-----------------------|-------------------------------|
| Release 6.0 | Version 6.0.0 |
| Release 6.3 | Version 6.3.0 |
| Release 7.0 | Version 7.0.1 |

Software Enhancements:

| OS | Change | Description |
|-----------|---------------|--|
| 2000/XP | New | Support Olympus Foot Switch RS-27 |
| 2000/XP | New | Support the DS-30/40/50 |
| 2000/XP | New | Support Podcast function and applicable Olympus recorders. |

Note: this update is inclusive of all previous updates and enhancement up to version 6.3.2.

Installation Instructions:

1. Click the **DSS Player V6 Upgrade to V7** link to start the download.
2. Save the file to your hard disk.
3. Close all open programs.
4. Double-click the DSSV7UPEN.EXE program file on your hard disk to start the update program.
5. Follow the instructions on the screen to complete the installation.