



TWO CORPORATE CENTER DRIVE  
MELVILLE, NY 11747-3157  
DIGITAL TECHNICAL SUPPORT  
CONSUMER PRODUCTS GROUP  
(888) 553-4448  
<http://support.olympusamerica.com>

### **Windows Compatibility for Digital Products**

Windows compatibility with Olympus digital products is supplied below by model. This information will be updated as additional testing is completed.

#### **Windows Compatibility For Camedia Master Software Versions**

<b>Software Version</b>	<b>Remarks</b>
Camedia Master 4.3	Windows 98, 98SE, 2000, ME, and XP are fully supported with Camedia Master 4.3
Camedia Master 4.2	Windows 98, 98SE, 2000, ME, and XP are fully supported with Camedia Master 4.2
Camedia Master 4.1	Windows 98, 2000, ME, and XP are fully supported with Camedia Master 4.1
Camedia Master 4.0	Windows 98, 2000, ME, and XP are fully supported with Camedia Master 4.0.
Camedia Master 2.5	In order to use the drag and drop functionality in Windows XP you will need to download and install the Camedia Master 2.51 patch for Windows XP compatibility located at <a href="http://www.olympusamerica.com/files/cm251_update.exe">http://www.olympusamerica.com/files/cm251_update.exe</a> This patch will not work on any other operating system.
Camedia Master 2.0	While you can download images using Camedia Master 2.0, you may experience incompatibilities when using the drag and drop feature in Windows 98, 2000, ME, and XP.
Digital Vision 3.0	The Digital Vision 3.0 software is functional but not officially supported with Windows 98, 2000, ME, and XP.



TWO CORPORATE CENTER DRIVE  
MELVILLE, NY 11747-3157  
DIGITAL TECHNICAL SUPPORT  
CONSUMER PRODUCTS GROUP  
(888) 553-4448  
<http://support.olympusamerica.com>

**Windows Compatibility For Auto Connect USB Digital Cameras**

<b>Model</b>	<b>Original Software</b>	<b>Remarks</b>
C-755 Zoom C-725 Zoom C-8080 Wide Zoom C-765 Ultra Zoom C-770 Ultra Zoom * C-725 Ultra Zoom Stylus 410 Digital D-540 Zoom D-575 Zoom Ferrari AZ-1	Camedia 4.2	The C-770 Ultra Zoom is shipped with Camedia Master 4.2SE. Ferrari AZ-1 ships with Camedia master 4.2 with the Formula 1 World Champion 1999-2003 Photo Collection.
Stylus 300 Digital Stylus 400 Digital Stylus 410 Digital D-390 D-560 Zoom D-565 Zoom D-580 Zoom C-740 Ultra Zoom C-750 Ultra Zoom C-5000 Zoom C-5060 Wide Zoom	Camedia 4.1	Olympus autoconnect USB Digital cameras are designed under USB storage-class specifications. This means that the camera's driver is included and automatically installed with Windows. Autoconnect USB cameras are recognized by Windows 2000, ME, and XP as a separate drive, which is listed as a "Removable Disk Drive". It is also assigned it's own unique drive letter in addition to your C drive and any other drive you may have. Because it is a separate drive, the Camedia Software is not necessary to download images. You can easily drag and drop images directly from the camera's assigned drive to any folder on your computer. *** See the Windows 98, 2000, ME, and XP Camedia version Compatibility Chart for further details regarding software compatibility.



TWO CORPORATE CENTER DRIVE  
 MELVILLE, NY 11747-3157  
 DIGITAL TECHNICAL SUPPORT  
 CONSUMER PRODUCTS GROUP  
 (888) 553-4448  
<http://support.olympusamerica.com>

D-380 D-520 Zoom D-550 Zoom C-50 Zoom C-720 Ultra Zoom C-730 Ultra Zoom C-4000 Zoom C-5050 Zoom	Camedia 4.0	Windows 98 users need to download and install the driver located at: <a href="http://www.olympusamerica.com/files/AutoConnDriv_Win98SE.exe">http://www.olympusamerica.com/files/AutoConnDriv_Win98SE.exe</a> .
--	-------------	---

**Windows Compatibility Chart For Auto Connect USB Digital Cameras (continued)**

<b>Model</b>	<b>Original Software</b>	<b>Remarks</b>
Brio D-100 Brio D-230 Brio D-150 Zoom D-370 D-510 Zoom D-40 Zoom C-700 Zoom C-2040 C-3020 C-3040 C-4040 Zoom E-100 RS E-10 E-20N	Camedia 2.0-2.5	Autoconnect USB cameras are recognized by Windows 2000, ME, and XP as a separate drive, which is listed as a "Removable Disk Drive". Because it is a separate drive, the Camedia Software is optional to download images. You can easily drag and drop images directly from the camera's assigned drive to any folder on your computer. *** See the Windows Windows 98, 2000, ME, and XP Camedia version Compatibility Chart for further details regarding software compatibility.  Windows 98 users need to download and install the Autoconnect USB driver located at <a href="http://www.olympusamerica.com/files/AutoConnDriv_Win98SE.exe">http://www.olympusamerica.com/files/AutoConnDriv_Win98SE.exe</a> .



TWO CORPORATE CENTER DRIVE  
MELVILLE, NY 11747-3157  
DIGITAL TECHNICAL SUPPORT  
CONSUMER PRODUCTS GROUP  
(888) 553-4448  
<http://support.olympusamerica.com>

### Windows Compatibility Chart For Standard USB Digital Cameras

Model	Original Software	Remarks
C-211 Zoom C-2100 Zoom C-3000 Zoom C-3030 Zoom	Camedia Master 2.0-2.5	Olympus standard USB digital cameras require installation of Windows 2000 USB device driver before 2000, ME, and XP can recognize the camera. The driver is located on the Camedia Master CD, or it can be downloaded at <a href="http://www.olympusamerica.com/files/win2000.exe">http://www.olympusamerica.com/files/win2000.exe</a> .  Windows 98 users need to download and install the Standard USB driver located at <a href="http://www.olympusamerica.com/files/Win_98.exe">http://www.olympusamerica.com/files/Win_98.exe</a>

### Windows Compatibility Chart For Serial Port Digital Cameras

Model	Original Software	Remarks
D-320L D-340L D-360L D-340R D-500 D-600 D-620L D-400 D-450 D-460 D-490 Zoom C-2000 C-2020 Zoom C-2500L C-21	Digital Vision 3.0 - Camedia Master 2.0	Olympus Serial Port Digital Cameras can connect using Windows 98, 2000, ME, and XP but require Camedia Master 2.51, or Camedia Master 4.x to download images.



TWO CORPORATE CENTER DRIVE  
 MELVILLE, NY 11747-3157  
 DIGITAL TECHNICAL SUPPORT  
 CONSUMER PRODUCTS GROUP  
 (888) 553-4448  
<http://support.olympusamerica.com>

**Windows Compatibility For Digital Camera Accessories**

<b>Accessory</b>	<b>Model</b>	<b>Remarks</b>
Flashpath Adapter	MAFP-1	The Windows 2000/XP Driver for the Flashpath Adapters can be installed using the download located at <a href="http://www.olympusamerica.com/files/FP_Win2kXP.exe">http://www.olympusamerica.com/files/FP_Win2kXP.exe</a> .
	MAFP-2	The Windows 95/98/ME Driver for the Flashpath Adapters can be installed using the download located at <a href="http://www.olympusamerica.com/files/FP-Win9x_ME.exe">http://www.olympusamerica.com/files/FP-Win9x_ME.exe</a>
PC Card Adapter	MA-1E MA-2E MAPC-10	The Windows XP operating system includes and will automatically install the necessary drivers for the PC Card Adapters.
USB Reader/Writer	MAUSB-1	The Windows XP Driver for the MAUSB-1 USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB_1_WinXP.exe">http://www.olympusamerica.com/files/MAUSB_1_WinXP.exe</a> .  The Windows 98/2000/ME Driver for the MAUSB-1 USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB1.exe">http://www.olympusamerica.com/files/MAUSB1.exe</a>
	MAUSB-4W	The Windows Driver for the MAUSB-4W USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB4W_XP.exe">http://www.olympusamerica.com/files/MAUSB4W_XP.exe</a>
	MAUSB-5W	The Windows ME and XP operating systems include and will automatically install the necessary drivers for the MAUSB-5W USB Reader/Writer.
		The Windows 98 Driver for the MAUSB-5W USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB5W_98.exe">http://www.olympusamerica.com/files/MAUSB5W_98.exe</a>  The Windows 2000 Driver for the MAUSB-5W USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB5W_2K.exe">http://www.olympusamerica.com/files/MAUSB5W_2K.exe</a>
MAUSB-10	The Windows Driver for the MAUSB-10 USB Reader/Writer can be installed using the driver located at <a href="http://www.olympusamerica.com/files/MAUSB10_Win.exe">http://www.olympusamerica.com/files/MAUSB10_Win.exe</a>	



TWO CORPORATE CENTER DRIVE  
 MELVILLE, NY 11747-3157  
 DIGITAL TECHNICAL SUPPORT  
 CONSUMER PRODUCTS GROUP  
 (888) 553-4448  
<http://support.olympusamerica.com>

	MAUSB-100	The Windows ME/2000/XP operating system includes and will automatically install the necessary drivers for the MAUSB-100 Reader/Writer. Windows 98 drivers are provided on the CD supplied with the MAUSB-100. The device is USB 2.0 Compatible.
	Microtech Zio! Reader	The Windows XP driver for the Microtech Zio! Reader can be downloaded from <a href="http://www.microtechint.com/downloads">http://www.microtechint.com/downloads</a> .
xD Compact Flash Adapter	MACF-10	The Windows XP operating system includes and will automatically install the necessary drivers for the xD Compact Flash Adapter.

### Windows Compatibility For Photo Printers

Model	Remarks
P-440	The Windows 98/ME/2000/XP compatible driver can be downloaded at <a href="http://www.olympusamerica.com/files/P440-Windows-98-Me-2000-XP.exe">http://www.olympusamerica.com/files/P440-Windows-98-Me-2000-XP.exe</a>
P-400	The Windows 2000/ XP compatible driver can be downloaded at <a href="http://www.olympusamerica.com/files/p400_win2000XP.exe">http://www.olympusamerica.com/files/p400_win2000XP.exe</a> The Windows 98/ME/NT compatible driver can be downloaded at <a href="http://www.olympusamerica.com/files/p400_Win98MENT.exe">http://www.olympusamerica.com/files/p400_Win98MENT.exe</a> .
P-10	The Windows 98/ME/2000/XP; Mac OS 10.2 to 10.3.x. Windows drivers are included on the CD supplied with the printer, Mac drivers were developed July, 2004 and are available on the web.
P-300	The Windows 95/98/ME compatible driver can be downloaded at <a href="http://www.olympusamerica.com/files/p300_win_95.exe">http://www.olympusamerica.com/files/p300_win_95.exe</a>
P-330N P-330	The Windows 95/98/ME compatible driver can be downloaded at <a href="http://www.olympusamerica.com/files/P330N_98.exe">http://www.olympusamerica.com/files/P330N_98.exe</a> .
P-200	Please contact Olympus Digital Technical Support for more information.



TWO CORPORATE CENTER DRIVE  
MELVILLE, NY 11747-3157  
DIGITAL TECHNICAL SUPPORT  
CONSUMER PRODUCTS GROUP

http://support.olympusamerica.com

### Windows Compatibility For Digital Voice Recorders

Model	Remarks
DS-660 W-10	These digital voice recorders are compatible with all Windows based operating systems.
DM-10 DM-20 DW-90 DS-2000 DS-2200 DS-3000 DS-4000 VN-240PC	These digital voice recorders are compatible with Windows 98, ME, 2000, and XP.
DS-330	These digital voice recorders are compatible with Windows 98, ME, 2000, XP and NT with Service Pack 4.
D-1000	To download files from the D-1000 to a computer with Windows NT, the optional Miniature Card Reader is required. The driver for the Miniature Card Reader is located at <a href="http://www.olympusamerica.com/files/minicardnt.zip">http://www.olympusamerica.com/files/minicardnt.zip</a> . To download files from the D-1000 to a laptop with Windows 95 or 98, the optional PC Card Adapter is required. The driver for the PC Card Adapter is located at <a href="http://www.olympusamerica.com/files/pccard98.zip">http://www.olympusamerica.com/files/pccard98.zip</a>
DS-150	These digital voice recorders are compatible with Windows 95, 98 and NT with Service Pack 4.
DM-1	The DM-1 cannot connect to the Windows 95, 98, or NT operating system. The latest version of Musicmatch and the Olympus DM-1 plug in can be downloaded at <a href="http://www.musicmatch.com">http://www.musicmatch.com</a> . We recommend downloading and installing the "DM-1 SmartMedia Update for Windows 2000/XP at <a href="http://www.olympusamerica.com/files/DM1SmartMediaupdate_2000XP.exe">http://www.olympusamerica.com/files/DM1SmartMediaupdate_2000XP.exe</a> .
V-90 VN-90 VN-900 VN-180 VN-1800 VN-3600	These stand-alone Digital Voice recorders cannot connect to a computer.