



TWO CORPORATE CENTER DRIVE
MELVILLE, NY 11747-3157
DIGITAL TECHNICAL SUPPORT
CONSUMER PRODUCTS GROUP
(888) 553-4448
<http://support.olympusamerica.com>

Installing the Printer Driver (During initial setup)

1. Connect printer to PC using a commercially available USB cable (Type A-B)
2. Start the PC, and insert the CD-ROM supplied with the printer into the CD-ROM drive.

The [New Hardware Found] dialog is automatically displayed.

- If this dialog is not automatically displayed, start installation of the driver by selecting [Settings – Printers – Add Printer] from the Start menu

If you are using Windows XP, start installation of the driver by selecting [Control Panel – Printers and Faxes – Add a printer] from the Start menu.

3. Follow the directions on the screen to install the printer driver.